

# **PURPLE ELEMENTS COMBO WITH POTTERY CASCADES**



### **SUPPLIES**

#### **Form**

MB-1556 Textured Bud Vases

#### Color

- EL-149 Lavender Flower
- EL-209 Night Sky
- PC-601 Clear Cascade
- PC-602 White Cascade

## **Decorating Accessories**

• RB-144 #4 Soft Fan

#### **Miscellaneous Accessories**

- Sponge
- Water
- Palette
- Disposable Cup

## **INSTRUCTIONS**

- 1. Begin with properly fired cone 04 bisque. Moisten a sponge and wipe bisque to remove any dust.
- 2. Pour around ¼ cup of EL-149 Lavender Flower into the disposable cup. Add around 1 TBS of water and mix. You want the glaze to be thin enough to be easily poured. Pour the glaze in to the vase. Rotate to cover the inside of the vase. Pour out any excess glaze.
- 3. Using the Soft Fan, apply 2 coats of EL-149 Lavender Flower to the outside of the vase. Allow glaze to dry between coats.
- 4. Pour around 2 TBS of PC-601 Clear Cascade, PC-602 White Cascade, EL-209 Night Sky and EL-149 Lavender Flower onto the palette.
- 5. Using the same Soft Fan, dip it into the PC-601 Clear Cascade and glob it randomly onto vase several times. You want to cover at least ¼ of the outside.
- 6. Using the same Soft Fan, dip it into the EL-209 Night Sky and glob it randomly onto vase. Make sure to put some globs over the PC-601 Clear Cascade. You want to cover at least ¼ of the outside.

- 7. Using the same Soft Fan, dip it into PC-602 White Cascade and add glob it randomly onto the vase. Make fewer, smaller globs.
- 8. Using the same Soft Fan, dip it into EL-149 Lavender Flower and add some more globs to the vase. Make sure to go over some of the PC-602 White Cascade.
- 9. Stilt and fire to cone 06.







