

Technique was achieved by brushing on two (2) layers of base glaze (EL-134 Mirror Blue). Then apply two (2) layers of top glaze, letting glazes dry between coats.





MB-1556 Textured Bud Vases shown are fired to Cone 06.

MaycoColors.com





Technique was achieved by brushing on two (2) layers of base glaze (EL-134 Mirror Blue). Then apply two (2) layers of top glaze, letting glazes dry between coats.





MB-1556 Textured Bud Vases shown are fired to Cone 06.



MaycoColors.com