

RAMEKIN SAND DOLLAR COMBINATION



SUPPLIES

Form

- SB-126 Ramekin

Color

- SW-196 Sand Dollar
- SW-190 Passion Flower
- SW-191 Peppered Plum

Decorating Accessories

- RB-140 #4 Soft Fan

Miscellaneous Accessories

- Sponge
- Water

INSTRUCTIONS

1. With a damp sponge, wipe SB-126 Ramekin to remove dust.
2. Apply 2 coats of SW-196 Sand Dollar to inside and out.
3. Apply 2 coats of SW-191 Peppered Plum to the sides of the inside of the ramekin, leaving an unglazed area in the middle.
4. Apply 2 coats of SW-190 Passion Flower to the center of the ramekin, overlapping a small portion of SW-191 Peppered Plum.
5. Apply SW-191 Peppered Plum to the outside rim of the ramekin. Use caution applying the crystal glazes on the outside of the ramekin, as they will flow and move. Application should be on the rim only.
6. Fire to cone 6.