



DESIGNER LINER, CRACKLE & SPECKLED STROKE & COAT



SUPPLIES

Form

- MB-1352 6x6" Square Clay Canvas

Color

- CC101 Transparent
- SG404 Blue
- SG410 Bright Blue
- SP212 Speckled Moody Blue
- SS138 Flat Black

Decorating Accessories

- RB144 #4 Soft Fan
- S446 Atomic Stencil or stencil of choice

Miscellaneous Accessories

- Sponge
- Water
- Pencil
- Paper Towels

INSTRUCTIONS

1. Begin with properly fired cone 04 bisque. Moisten a sponge and wipe bisque to remove any dust.
2. Center the Stencil on the canvas. Trace with the pencil.
3. Use SG404 Blue and SG410 Bright Blue to trace over the pattern. Add lines and dots to make the pattern more interesting. Allow Designer Liner to dry completely before continuing.
4. Using the Soft Fan, apply 3 coats of CC101 Transparent to the top of the canvas. Allow glaze to dry between coats.
5. Using the Soft Fan, apply 3 coats of SP212 Speckled Moody Blue to the edges of the canvas.
6. Allow glaze to dry between coats.
7. Fire to cone 06.
8. Thin SS138 with water. Use a sponge to apply over the top of the canvas. Wipe off with a paper towel.